


**3RT1 contactors**  
**Sizes S6 to S12 with mountable accessories**  
*(illustration for basic unit)*



For accessories and spare parts, see pages 3/75 to 3/123.

# Power Contactors for Switching Motors

## Accessories and Spare Parts for SIRIUS 3RT Contactors and SIRIUS 3RH2 Contactor Relays Accessories

### Auxiliary switch blocks, instantaneous

PU (UNIT, SET, M) = 1  
 PS\* = 1 unit  
 PG = 41B



3RH1921-1DA11,  
 3RH1921-1JA11,  
 3RH1921-1EA...  
 3RH1921-1KA...



3RH1921-2DA11,  
 3RH1921-2JA11,  
 3RH1921-2EA...  
 3RH1921-2KA...

For contactors	Auxiliary contacts	SD	Screw terminals	SD	Spring-type terminals
	Version		Article No.		Article No.
	Type		Price per PU		Price per PU
	NO NC	d		d	

### Lateral auxiliary switch blocks, mounting on the left or right, 2-pole

#### Sizes S6 to S12

	Left	Right		
<b>First auxiliary switch block</b>				
• Acc. to EN 50012				
3RT1.5 ... 3RT1.7	1 1		▶ <b>3RH1921-1DA11</b>	▶ <b>3RH1921-2DA11</b>
• Acc. to EN 50005				
3RT1.5 ... 3RT1.7	2 --		▶ <b>3RH1921-1EA20</b>	▶ <b>3RH1921-2EA20</b>
	1 1		▶ <b>3RH1921-1EA11</b>	--
	-- 2		▶ <b>3RH1921-1EA02</b>	▶ <b>3RH1921-2EA02</b>
<b>Second auxiliary switch block</b>				
• Acc. to EN 50012				
3RT1.5 ... 3RT1.7	1 1		▶ <b>3RH1921-1JA11</b>	▶ <b>3RH1921-2JA11</b>
• Acc. to EN 50005				
3RT1.5 ... 3RT1.7	2 --		▶ <b>3RH1921-1KA20</b>	20 ▶ <b>3RH1921-2KA20</b>
	1 1		▶ <b>3RH1921-1KA11</b>	--
	-- 2		▶ <b>3RH1921-1KA02</b>	20 ▶ <b>3RH1921-2KA02</b>