

Switch disconnectors

COMMAND Series

590.



Base mounting  
[63A-160A]

Version	Current	Poles	Switch size	SWITCH DISCONNECTOR			
63A	Y2	2P	590.YA632B <sup>[4]</sup>	6			
		3P	590.YA633B <sup>[4]</sup>	6			
		4P	590.YA634B <sup>[4]</sup>	6			
		3P+N	590.YA635B <sup>[3][4]</sup>	6			
	Y4	6P	590.YA636B <sup>[1][2]</sup>		6		
		8P	590.YA638B <sup>[1][3][2]</sup>		6		
80A	Y2	2P	590.YA802B <sup>[4]</sup>	6			
		3P	590.YA803B <sup>[4]</sup>	6			
		4P	590.YA804B <sup>[4]</sup>	6			
		3P+N	590.YA805B <sup>[3][4]</sup>	6			
BOX (B)	Y4	6P	590.YA806B <sup>[1][2]</sup>		6		
		8P	590.YA808B <sup>[1][3][2]</sup>		6		
	Y5	3P	590.YA1003B <sup>[1][2]</sup>		6		
		4P	590.YA1004B <sup>[1][2]</sup>		6		
		3P+N	590.YA1005B <sup>[1][3][2]</sup>		6		
		6P	590.YA1006B <sup>[1][2]</sup>		6		
100A	Y5	8P	590.YA1008B <sup>[1][3][2]</sup>		6		
		125A	3P	590.YA1253B <sup>[1][2]</sup>		6	
			3P+N	590.YA1255B <sup>[1][3][2]</sup>		6	
6P	590.YA1256B <sup>[1][2]</sup>			6			
160A	Y5	8P	590.YA1258B <sup>[1][3][2]</sup>		6		
		3P	590.YA1603B <sup>[1][2]</sup>		5		
		3P+N	590.YA1605B <sup>[1][3][2]</sup>		5		
	Y5	6P	590.YA1606B <sup>[1][2]</sup>		6		
		160A	8P	590.YA1608B <sup>[1][3][2]</sup>		6	

- <sup>[1]</sup> Equipped with direct handle
- <sup>[2]</sup> DIN rail / screw fixing
- <sup>[3]</sup> With late break and early make neutral pole
- <sup>[4]</sup> DIN rail fixing
- BOX (B) = Base mounting

1.5

