

CONTACTORI PENTRU INSTALAȚII



5TT5000-0



5TT5033-0

Ue V AC	Ie A AC	Uc V AC	Contact			Cod comandă
			NO	NC	UM	
	20	230	2	-	1	5TT5000-0
250						
			1	1		5TT5001-0
			-	2		5TT5002-0
	25	230	4	-	2	5TT5030-0
440			3	1		5TT5031-0
			2	2		5TT5032-0
			-	4		5TT5033-0
440	40	230	4	-	3	5TT5040-0
440			3	1		5TT5041-0
			2	2		5TT5042-0
			-	4		5TT5043-0
	63	230	4	-	3	5TT5050-0
			3	1		5TT5051-0
			2	2		5TT5052-0

Contacte auxiliare pentru seria 5TT58

Maxim 1 contact auxiliar pentru 1 contactor



5TT5910-0

230	6	-	2	-	0,5	5TT5910-0
AC-15						
230	6	-	1	1	0,5	5TT5910-1
AC-15						