




ROZDZIELNICE FEMO 18M



		IP65	Moduły	Op.	J.m.
74191	Obudowa FEMO 18M		18 modułów	1/1	szt.
74191.3	FEMO 18M - gniazda 16A 5p, 3x32A 5p, 4x230V		18 modułów	1/1	szt.
74191.4	FEMO 18M - gniazda 2x16A 5p, 2x32A 5p, 4x230V		18 modułów	1/1	szt.
74191.5	FEMO 18M - gniazda 3x16A 5p, 32A 5p, 4x230V		18 modułów	1/1	szt.
74191.1	FEMO 18M - gniazda 4x16A 5p, 4x230V		18 modułów	1/1	szt.
74191.2	FEMO 18M - gniazda 4x32A 5p, 4x230V		18 modułów	1/1	szt.



			Moduły	Op.	J.m.
74191.8	FEMO 18M - gniazda 16A 5p, 3x32A 5p, 6x230V		18 modułów	1/1	szt.
74191.9	FEMO 18M - gniazda 2x16A 5p, 2x32A 5p, 6x230V		18 modułów	1/1	szt.
74191.10	FEMO 18M - gniazda 3x16A 5p, 32A 5p, 6x230V		18 modułów	1/1	szt.
74191.6	FEMO 18M - gniazda 4x16A 5p, 6x230V		18 modułów	1/1	szt.
74191.7	FEMO 18M - gniazda 4x32A 5p, 6x230V		18 modułów	1/1	szt.



			Moduły	Op.	J.m.
74191.29	FEMO 18M - gniazda 2x16A 5p, 6x32A 5p		18 modułów	1/1	szt.
74191.30	FEMO 18M - gniazda 3x16A 5p, 5x32A 5p		18 modułów	1/1	szt.
74191.31	FEMO 18M - gniazda 4x16A 5p, 4x32A 5p		18 modułów	1/1	szt.
74191.32	FEMO 18M - gniazda 5x16A 5p, 3x32A 5p		18 modułów	1/1	szt.
74191.33	FEMO 18M - gniazda 6x16A 5p, 2x32A 5p		18 modułów	1/1	szt.
74191.34	FEMO 18M - gniazda 8x16A 5p		18 modułów	1/1	szt.
74191.35	FEMO 18M - gniazda 8x32A 5p		18 modułów	1/1	szt.