




ROZDZIELNICE KOMBI



		Op.	J.m.
F3.0809	KOMBI - gniazda 16A 3p, 230V	1/1	szt.
F3.0812	KOMBI - gniazda 32A 3p, 230V	1/1	szt.
F3.0810	KOMBI - gniazda 16A 3p, 2x230V	1/1	szt.
F3.0813	KOMBI - gniazda 32A 3p, 2x230V	1/1	szt.
F3.0811	KOMBI - gniazda 16A 3p, 3x230V	1/1	szt.
F3.0814	KOMBI - gniazda 32A 3p, 3x230V	1/1	szt.
F3.0052	KOMBI - gniazda 16A 5p, 230V	1/1	szt.
F3.0058	KOMBI - gniazda 32A 5p, 230V	1/1	szt.
F3.0053	KOMBI - gniazda 16A 5p, 2x230V	1/1	szt.
F3.0059	KOMBI - gniazda 32A 5p, 2x230V	1/1	szt.
F3.0054	KOMBI - gniazda 16A 5p, 3x230V	1/1	szt.
F3.0060	KOMBI - gniazda 32A 5p, 3x230V	1/1	szt.



		Funkcja wyłącznika	Op.	J.m.
F3.0803	KOMBI - gniazda 16A 3p	0/1 (16A)	1/1	szt.
F3.0806	KOMBI - gniazda 32A 3p	0/1 (25A)	1/1	szt.
F3.0804	KOMBI - gniazda 16A 3p, 230V	0/1 (16A)	1/1	szt.
F3.0807	KOMBI - gniazda 32A 3p, 230V	0/1 (25A)	1/1	szt.
F3.0805	KOMBI - gniazda 16A 3p, 2x230V	0/1 (16A)	1/1	szt.
F3.0808	KOMBI - gniazda 32A 3p, 2x230V	0/1 (25A)	1/1	szt.



		Funkcja wyłącznika	Op.	J.m.
F3.0004	KOMBI - gniazda 16A 5p	0/1 (16A)	1/1	szt.
F3.0010	KOMBI - gniazda 32A 5p	0/1 (32A)	1/1	szt.
F3.0005	KOMBI - gniazda 16A 5p, 230V	0/1 (16A)	1/1	szt.
F3.0011	KOMBI - gniazda 32A 5p, 230V	0/1 (32A)	1/1	szt.
F3.0006	KOMBI - gniazda 16A 5p, 2x230V	0/1 (16A)	1/1	szt.
F3.0012	KOMBI - gniazda 32A 5p, 2x230V	0/1 (32A)	1/1	szt.
F3.0016	KOMBI - gniazda 16A 5p	L/P (16A)	1/1	szt.
F3.0022	KOMBI - gniazda 32A 5p	L/P (32A)	1/1	szt.
F3.0017	KOMBI - gniazda 16A 5p, 230V	L/P (16A)	1/1	szt.
F3.0023	KOMBI - gniazda 32A 5p, 230V	L/P (32A)	1/1	szt.
F3.0018	KOMBI - gniazda 16A 5p, 2x230V	L/P (16A)	1/1	szt.
F3.0024	KOMBI - gniazda 32A 5p, 2x230V	L/P (32A)	1/1	szt.