




		Moduły	Op.	J.m.
F3.0833	CAJA 12M - gniazda 16A 5p, 63A 5p, 2x230V	12 modułów	1/1	szt.
F3.0834	CAJA 12M - gniazda 16A 5p, 63A 5p, 3x230V	12 modułów	1/1	szt.
F3.0835	CAJA 12M - gniazda 16A 5p, 63A 5p, 4x230V	12 modułów	1/1	szt.



		Moduły	Op.	J.m.
F3.0836	CAJA 12M - gniazda 32A 5p, 63A 5p, 2x230V	12 modułów	1/1	szt.
F3.0837	CAJA 12M - gniazda 32A 5p, 63A 5p, 3x230V	12 modułów	1/1	szt.
F3.0838	CAJA 12M - gniazda 32A 5p, 63A 5p, 4x230V	12 modułów	1/1	szt.



		Funkcja wyłącznika	Moduły	Op.	J.m.
F3.0458	CAJA 12M - gniazda 16A 5p, 32A 5p, 2x230V	0/1 (32A)	12 modułów	1/1	szt.
F3.0459	CAJA 12M - gniazda 2x16A 5p, 2x230V	0/1 (32A)	12 modułów	1/1	szt.
F3.0460	CAJA 12M - gniazda 2x32A 5p, 2x230V	0/1 (32A)	12 modułów	1/1	szt.
F3.0461	CAJA 12M - gniazda 16A 5p, 32A 5p, 2x230V	L/P (32A)	12 modułów	1/1	szt.
F3.0462	CAJA 12M - gniazda 2x16A 5p, 2x230V	L/P (32A)	12 modułów	1/1	szt.
F3.0463	CAJA 12M - gniazda 2x32A 5p, 2x230V	L/P (32A)	12 modułów	1/1	szt.



		Funkcja wyłącznika	Moduły	Op.	J.m.
F3.0839	CAJA 12M - gniazda 16A 5p, 63A 5p, 2x230V	0/1 (63A)	12 modułów	1/1	szt.
F3.0841	CAJA 12M - gniazda 32A 5p, 63A 5p, 2x230V	0/1 (63A)	12 modułów	1/1	szt.
F3.0840	CAJA 12M - gniazda 16A 5p, 63A 5p, 2x230V	L/P (63A)	12 modułów	1/1	szt.
F3.0842	CAJA 12M - gniazda 32A 5p, 63A 5p, 2x230V	L/P (63A)	12 modułów	1/1	szt.