

ROZDZIELNICE TRIBOX



A	C	A	98
B	B	B	373
	C	C	50



		Op.	J.m.
F3.0578	TRIBOX - gniazda 16A 5p, 2x32A 5p	1/1	szt.
F3.0577	TRIBOX - gniazda 2x16A 5p, 32A 5p	1/1	szt.
F3.0575	TRIBOX - gniazda 3x16A 5p	1/1	szt.
F3.0576	TRIBOX - gniazda 3x32A 5p	1/1	szt.



A	C	A	98
B	B	B	373
	C	C	50



		Wtyczka	Przewód	Op.	J.m.
F3.0579	TRIBOX - gniazda 3x16A 5p	16A 5p	/3m/ OW 5x2,5mm <sup>2</sup>	1/1	szt.
F3.0580	TRIBOX - gniazda 3x16A 5p	16A 5p	/5m/ OW 5x2,5mm <sup>2</sup>	1/1	szt.
F3.0581	TRIBOX - gniazda 3x16A 5p	16A 5p	/10m/ OW 5x2,5mm <sup>2</sup>	1/1	szt.
F3.0582	TRIBOX - gniazda 3x32A 5p	32A 5p	/3m/ OPD 5x4,0mm <sup>2</sup>	1/1	szt.
F3.0583	TRIBOX - gniazda 3x32A 5p	32A 5p	/5m/ OPD 5x4,0mm <sup>2</sup>	1/1	szt.
F3.0584	TRIBOX - gniazda 3x32A 5p	32A 5p	/10m/ OPD 5x4,0mm <sup>2</sup>	1/1	szt.

ROZDZIELNICE PARMA



A	C	A	78
B	B	B	127
	C	C	78



		Wtyk	I <sub>[A]</sub>	Op.	J.m.
F3.0379	PARMA - gniazda 16A 5p, 2x32A 5p	16A 5p	16A	1/1	szt.
F3.0364	PARMA - gniazda 2x16A 5p, 32A 5p	16A 5p	16A	1/1	szt.
F3.0112	PARMA - gniazda 3x16A 5p	16A 5p	16A	1/1	szt.
F3.0113	PARMA - gniazda 3x32A 5p	32A 5p	32A	1/1	szt.



A	C	A	78
B	B	B	127
	C	C	78



		Wtyk	I <sub>[A]</sub>	Op.	J.m.
F3.0117	PARMA - gniazda 2x16A 5p, 230V	16A 5p	16A	1/1	szt.
F3.0363	PARMA - gniazda 2x32A 5p, 230V	32A 5p	32A	1/1	szt.
F3.0116	PARMA - gniazda 16A 5p, 2x230V	16A 5p	16A	1/1	szt.
F3.0380	PARMA - gniazda 32A 5p, 2x230V	32A 5p	32A	1/1	szt.
F3.0377	PARMA - gniazda 3x230V	16A 5p	16A	1/1	szt.
F3.0378	PARMA - gniazda 3x230V	32A 5p	32A	1/1	szt.