



## ROZDZIELNICE CAJA 26M



		Moduły	Op.	J.m.
<b>F3.0817</b>	CAJA 26M - gniazda 16A 5p, 2x32A 5p, 8x230V	26 modułów	1/1	szt.
<b>F3.0818</b>	CAJA 26M - gniazda 2x16A 5p, 32A 5p, 8x230V	26 modułów	1/1	szt.
<b>F3.0815</b>	CAJA 26M - gniazda 3x16A 5p, 8x230V	26 modułów	1/1	szt.
<b>F3.0816</b>	CAJA 26M - gniazda 3x32A 5p, 8x230V	26 modułów	1/1	szt.
<b>F3.0821</b>	CAJA 26M - gniazda 16A 5p, 2x32A 5p, 10x230V	26 modułów	1/1	szt.
<b>F3.0822</b>	CAJA 26M - gniazda 2x16A 5p, 32A 5p, 10x230V	26 modułów	1/1	szt.
<b>F3.0819</b>	CAJA 26M - gniazda 3x16A 5p, 10x230V	26 modułów	1/1	szt.
<b>F3.0820</b>	CAJA 26M - gniazda 3x32A 5p, 10x230V	26 modułów	1/1	szt.



		Moduły	Op.	J.m.
<b>F3.0825</b>	CAJA 26M - gniazda 16A 5p, 3x32A 5p, 4x230V	26 modułów	1/1	szt.
<b>F3.0826</b>	CAJA 26M - gniazda 2x16A 5p, 2x32A 5p, 4x230V	26 modułów	1/1	szt.
<b>F3.0827</b>	CAJA 26M - gniazda 3x16A 5p, 32A 5p, 4x230V	26 modułów	1/1	szt.
<b>F3.0823</b>	CAJA 26M - gniazda 4x16A 5p, 4x230V	26 modułów	1/1	szt.
<b>F3.0824</b>	CAJA 26M - gniazda 4x32A 5p, 4x230V	26 modułów	1/1	szt.
<b>F3.0830</b>	CAJA 26M - gniazda 16A 5p, 3x32A 5p, 6x230V	26 modułów	1/1	szt.
<b>F3.0831</b>	CAJA 26M - gniazda 2x16A 5p, 2x32A 5p, 6x230V	26 modułów	1/1	szt.
<b>F3.0832</b>	CAJA 26M - gniazda 3x16A 5p, 32A 5p, 6x230V	26 modułów	1/1	szt.
<b>F3.0828</b>	CAJA 26M - gniazda 4x16A 5p, 6x230V	26 modułów	1/1	szt.
<b>F3.0829</b>	CAJA 26M - gniazda 4x32A 5p, 6x230V	26 modułów	1/1	szt.