



FLUSH-MOUNTING BOX FOR PLASTERBOARD WALLS

For panels	Outer dim.	Characteristics	Pack
	LxHxD (mm)		Carton
Master ICE 10"	306x238x80	Halogen free	1/14
		LxHxD (mm)	LxHxD (mm)

GW 24 101 PM

## **COMMAND DEVICES**

## TOUCH PUSH-BUTTON PANELS



## KNX 6-CHANNEL TOUCH PUSH-BUTTON PANEL MODULE WITH INTERCHANGEABLE SYMBOLS

Code	No.	No. Chorus	Pack
	channels	modules	Carton
GW A9 421	6	3	1

can be personalised using a set of adhesive icons. To be completed with the glass ICE Touch KNX plate (code GW16946CB, GW16946CB, GW16946CT). The device's touch commands can only be activated with the plate mounted: therefore, to configure the module the ICE Touch KNX plates or alternative the test plate (GW16950) must be used. To be configured with ETS software. **APPLICATIONS:** used for sending ON-OFF commands with fronts management, switching commands and sequences, timed commands, multiple pressing, priority commands, commands for managing roller shutters (single or double push-button), dimmers (single or double push-button) and scenes (storage and activation). **NOTES:** equipped with coupling terminal with protection lid, for connection to BUS, and with set of icons to personalise the functions of each channel.

GW A9 421



ICE TOUCH KNX - WHITE

Code	Description	For support	Pack		
		codes	Carton		
GW 16 946 CB	6 touch areas	GW16803	1		

CHARACTERISTICS: plates made in glass with a glossy finish, used to complete the touch push-button panel modules - KNX (GWA9421) or Easy (GWA9471). The plates have 6 capacitive touch areas.

NOTES: the symbols shown in the picture are indicative only: they can be personalised using the set of adhesive icons included in the touch push-button module package. The code of the plate is unique and independent from the number of channels that you want to activate (from 1 to 6).

GW 16 946 CB




ICE TOUCH KNX - BLACK					
Code	Description	For support	Pack		
		codes	Carton		
GW 16 946 CN	6 touch areas	GW16803	1		

CHARACTERISTICS: plates made in glass with a glossy finish, used to complete the touch push-button panel modules - KNX (GWA9421) or Easy (GWA9471). The plates have 6 capacitive touch areas.


NOTES: the symbols shown in the picture are indicative only: they can be personalised using the set of adhesive icons included in the touch push-button module package. The code of the plate is unique and independent from the number of channels that you want to activate (from 1 to 6).


GW 16 946 CN






## Chorus











DOMESTIC RANGES







231