








Colour	MOMENTARY ROUND PUSH-BUTTONS					
	With guard		Without guard		With backlit guard	
Green	GW 74 301		GW 74 313		GW 74 341	
Black	GW 74 302		GW 74 312		-	
White	GW 74 303		GW 74 314		GW 74 342	
Red	GW 74 304		GW 74 311		GW 74 343	
Blue	GW 74 305		GW 74 315		GW 74 344	
Yellow	GW 74 306		GW 74 316		GW 74 345	


Colour	ROUND MUSHROOM-HEAD PUSH-BUTTONS - Ø 40 MM			
	With holding		Without holding	
Red	GW 74 364		GW 74 363	
	GW 74 367		GW 74 366	

Colour	ROUND MUSHROOM-HEAD EMERGENCY PUSH-BUTTONS - Ø 40 MM			
	With holding		With holding and key	
Red	GW 74 361		GW 74 362	
	GW 74 365			

In bold, the illuminated versions

Positions	ROUND SELECTORS					
	Lever type with fixed positions		Extractable key with fixed position		Lever type with return	
0 - 1	GW 74 401		GW 74 411		GW 74 421	
1 - 0 - 2	GW 74 402		GW 74 412		GW 74 422	

Colour	LUMINOUS INDICATORS	
	Direct power supply	
Green	GW 74 451	
Red	GW 74 452	
Yellow	GW 74 453	
Light blue	GW 74 454	
White	GW 74 455	

COMPLEMENTARY ITEMS			
Type	Contact		
Single contact	1 NO	GW 74 501	
	1 NC	GW 74 502	
Dual contact	2 NO	GW 74 503	
	2 NC	GW 74 505	
	1 NO + 1 NC	GW 74 504	
	Lamp-holder - BA9S coupling	GW 74 511	

COMPLETE CONTAINERS				
Indicator lights Ø 22	With guard	No. gangs	Contacts	Dimensions (LxHxD) mm
Generic (black)	GW 27 201	1	1 NO	66x82x65
Emergency (red)	GW 27 202	1	1 NO 1 NC	66x82x65
Start (green)	GW 27 203	2	1 NO 1 NC	132x82x65
Stop (red)				
Start (green)	GW 27 204	3	1 NO 1 NC	66x171x65
Stop (red)				
Signalling (white)				

EMPTY CONTAINERS					
No. gangs	Code	Side entries	Top / Bottom entries	Dimensions (LxHxD) mm	
1	GW 27 101	2 x Ø 23	2 x Ø 23	66x82x65	
1	GW 27 111 (*)	2 x Ø 23	2 x Ø 23	66x82x65	
2	GW 27 102	6 x Ø 23	2 x Ø 23	132x82x65	
3	GW 27 103	4 x Ø 23	2 x Ø 23	66x171x65	
6	GW 27 104	4 x Ø 23	6 x Ø 23	132x171x65	
12	GW 27 105	4 x Ø 23	6 x Ø 23	264x171x65	

(*) GW 27 111: yellow lid and grey back-mounting box - Specific for emergency push-buttons.

For all illuminated versions, the LED lamp must be purchased separately: GW 74 515 (12V); GW 74 516 (24V); GW 74 517 (110V); GW 74 518 (230V).



GW 74 523

PLATES

Code	Suitable for	Shape	Colour	Text	Pack Carton
GW 74 522	Push-buttons, indicators and selectors Ø 22mm	Rectangular	Black	-	5/100
GW 74 523	Mushroom-head emergency button	Round	Yellow	Emergency-Stop	10/100

CHARACTERISTIC: the plates allow you to assign the push-button, selector and indicator functions.

NOTE: GW74523 to be used when the emergency push-buttons are installed on the panel.





GW 74 525

TOOLS



Code	Description	Material	Pack Carton
GW 74 524	Tool for mounting ring nuts	Metal	10/100
GW 74 525	extraction tool Lamp	Thermoplastic	10/100

Dimension tables



INDICATORS





GW 74 301 ÷ GW 74 306



GW 74 311 ÷ GW 74 316




GW 74 341 ÷ GW 74 345




GW 74 363 - GW 74 364
GW 74 366 - GW 74 367

Dimension tables


INDICATORS




GW 74 361 - GW 74 365




GW 74 401 - GW 74 402
GW 74 421 - GW 74 422



GW 74 451 ÷ GW 74 455



GW 74 501 - GW 74 502



GW 74 503 ÷ GW 74 505