

## ACCESSORIES FOR MCCB'S

### CONNECTORS FOR ACCESSORIES



GW D8 133

#### CONNECTORS FOR ACCESSORIES FOR PLUG-IN AND WITHDRAWABLE VERSIONS

Code	Type of accessory	Type of accessory	Number of three-way switches	Number of pin	Pack Carton
<b>Suitable for: MTX/E/M 160/c-250</b>					
GW D8 133	Opening releases			3	1
GW D8 134	Frontal motor operating	Auxiliary contacts	2	6	1
GW D8 135	Auxiliary contacts		4	12	1
<b>Suitable for: MTX/E/M 320-1000</b>					
GW D8 164	Opening releases			5	1
GW D8 165	Auxiliary contacts		2	6	1
GW D8 166	Motor operating	Opening releases		10	1
GW D8 167	Auxiliary contacts		4	12	1

**NOTE:** for the MTXE 160 auxiliary contacts (3 three-way switches), it is necessary to use both the GW D8133 and GW D8134 connector.

The GW D8134 is always supplied with the frontal motor operating.

In the case of installation of both motor operating and auxiliary contacts it is necessary to use the GW D8166 connectors for MTX/E/M 320-1000.

### ACCESSORIES FOR FIXED PARTS



GW D8 158

#### POSITION CONTACTS FOR FIXED PART OF PLUG-IN OR WITHDRAWABLE VERSIONS

Code	Type of indicator	Pack Carton
<b>Suitable for: MTX/E/M 160-250</b>		
GW D8 158	Switch in	1
<b>Suitable for: MTX/E/M 320-1000</b>		
GW D8 159	Switch in	1
GW D8 160	Switch out	1



GW D8 086

#### KEY LOCK FOR FIXED PART OF WITHDRAWABLE VERSIONS

Code	Type	Key	Pack Carton
<b>Suitable for: MTX/E/M 320-1000</b>			
GW D8 086	Key lock		1
GW D8 087	Key lock	RONIS	1



GW D8 091

#### INSULATION TERMINAL COVERS FOR FIXED PARTS

Code	No. of poles	Pack Carton
<b>Suitable for: MTX/E/M 320</b>		
GW D8 091	3P	1
GW D8 092	4P	1
<b>Suitable for: MTXM 400-MTX/E/M 630</b>		
GW D8 093	3P	1
GW D8 094	4P	1