

OPENING RELEASES



GW D8 101

SHUNT TRIP RELEASES

Code	Supply voltage	Pack Carton
Suitable for: MTX/E/M 160/c-250		
GW D8 101	12 V dc	1
GW D8 102	24-30 V ac/dc	1
GW D8 103	48-60 V ac/dc	1
GW D8 104	127 V ac - 125 V dc	1
GW D8 105	240 V ac - 250 V dc	1
GW D8 106	380-440 V ac	1
Suitable for: MTX/E/M 320-1000		
GW D8 107	24-30 V ac/dc	1
GW D8 108	48-60 V ac/dc	1
GW D8 109	127 V ac - 125 V dc	1
GW D8 110	240 V ac - 250 V dc	1
GW D8 111	380-440 V ac	1



GW D8 117

UNDER VOLTAGE RELEASES

Code	Supply voltage	Pack Carton
Suitable for: MTX/E/M 160/c-250		
GW D8 117	24-30 V ac/dc	1
GW D8 118	48 V ac/dc	1
GW D8 119	127 V ac - 125 V dc	1
GW D8 120	240 V ac - 250 V dc	1
GW D8 121	380-400 V ac	1
Suitable for: MTX/E/M 320-1000		
GW D8 122	24-30 V ac/dc	1
GW D8 123	48 V ac/dc	1
GW D8 124	127 V ac - 125 V dc	1
GW D8 125	240 V ac - 250 V dc	1
GW D8 126	380-400 V ac	1



GW D8 136

ELECTRONIC DELAY DEVICE FOR UNDER VOLTAGE RELEASES

Code	Suitable for	Supply voltage	Pack Carton
GW D8 136	MTX/E/M 160/c-1000	220-250 V ac/dc	1

NOTE: the GW D8136 can only be used with the under voltage release with power supply voltage 240 V ac - 250 V dc.

AUXILIARY CONTACTS



GW D8 141

AUXILIARY CONTACTS

Code	No. CO contact	No. CO fault indic. switch	Contact rating in AC (A)	Contact rating in DC (A)	Pack Carton
Suitable for: MTX/M 160/c-250					
GW D8 141	3	1	6(125 V)-5(250 V)	0.3(125 V)-0.15(250 V)	1
GW D8 142	1	1	6(125 V)-5(250 V)	0.3(125 V)-0.15(250 V)	1
Suitable for: MTXE 160					
GW D8 151	1	2	6(125 V)-5(250 V)	0.3(125 V)-0.15(250 V)	1
GW D8 152	2	1	6(125 V)-5(250 V)	0.3(125 V)-0.15(250 V)	1
Suitable for: MTX/E/M 320-1000					
GW D8 143	1	1	6(125 V)-5(250 V)	0.3(125 V)-0.15(250 V)	1
GW D8 144	3	1	6(125 V)-5(250 V)	0.3(125 V)-0.15(250 V)	1
GW D8 145	1	1	12(250 V)-3(400 V)	0.5(125 V)-0.3(250 V)	1
GW D8 146	2	-	12(250 V)-3(400 V)	0.5(125 V)-0.3(250 V)	1

NOTE: one of the two CO fault indicator switches of the GW D8151 indicates the tripping of the electronic release.