


PAp10-3-OP modular socket

This socket is intended for installing into the distribution board and serves for connecting a portable light or low-power electric tool when performing maintenance and service works on the electric unit in situ.

Range



ZD-47 emergency bell

ZD-47 serves for giving out signals of an emergency in the operated electric circuit.

Range

