Colour	MOMENTARY ROUND PUSH-BUTTONS					
	With guard		Without guard		With backlit guard	
Green	GW 74 301		GW 74 313		**GW 74 341**	
Black	GW 74 302		GW 74 312		-	
White	GW 74 303		GW 74 314		**GW 74 342**	
Red	GW 74 304		GW 74 311		**GW 74 343**	
Blue	GW 74 305		GW 74 315		**GW 74 344**	
Yellow	GW 74 306		GW 74 316		**GW 74 345**	

Colour	ROUND MUSHROOM-HEAD PUSH-BUTTONS - Ø 40 MM			
	With holding		Without holding	
Red	GW 74 364		GW 74 363	
	GW 74 367		**GW 74 366**	

Colour	ROUND MUSHROOM-HEAD EMERGENCY PUSH-BUTTONS - Ø 40 MM			
	With holding		With holding and key	
Red	GW 74 361		GW 74 362	
	GW 74 365			

In bold, the illuminated versions

Positions	ROUND SELECTORS					
	Lever type with fixed positions		Extractable key with fixed position		Lever type with return	
0 - 1	GW 74 401		GW 74 411		GW 74 421	
1 - 0 - 2	GW 74 402		GW 74 412		GW 74 422	

Colour	LUMINOUS INDICATORS	
	Direct power supply	
Green	GW 74 451	
Red	GW 74 452	
Yellow	GW 74 453	
Light blue	GW 74 454	
White	GW 74 455	

COMPLEMENTARY ITEMS			
Type		Contact	
Single contact	1 NO	GW 74 501	
	1 NC	GW 74 502	
Dual contact	2 NO	GW 74 503	
	2 NC	GW 74 505	
	1 NO + 1 NC	GW 74 504	
Lamp-holder - BA9S coupling		GW 74 511	

COMPLETE CONTAINERS					
Indicator lights Ø 22	With guard		No. gangs	Contacts	Dimensions (LxHxD) mm
Generic (black)	GW 27 201		1	1 NO	66x82x65
Emergency (red)	GW 27 202		1	1 NO 1 NC	66x82x65
Start (green)	GW 27 203		2	1 NO 1 NC	132x82x65
Stop (red)					
Start (green)	GW 27 204		3	1 NO 1 NC	66x171x65
Stop (red)					
Signalling (white)					

EMPTY CONTAINERS					
No. gangs	Code		Side entries	Top / Bottom entries	Dimensions (LxHxD) mm
1	GW 27 101		2 x Ø 23	2 x Ø 23	66x82x65
1	GW 27 111 (*)		2 x Ø 23	2 x Ø 23	66x82x65
2	GW 27 102		6 x Ø 23	2 x Ø 23	132x82x65
3	GW 27 103		4 x Ø 23	2 x Ø 23	66x171x65
6	GW 27 104		4 x Ø 23	6 x Ø 23	132x171x65
12	GW 27 105		4 x Ø 23	6 x Ø 23	264x171x65

(*) GW 27 111: yellow lid and grey back-mounting box - Specific for emergency push-buttons.
For all illuminated versions, the LED lamp must be purchased separately: GW 74 515 (12V); GW 74 516 (24V); GW 74 517 (110V); GW 74 518 (230V).

MUSHROOM-HEAD PUSH-BUTTONS

GW 74 367

ROUND MUSHROOM-HEAD PUSH-BUTTONS - MUSHROOM Ø 40MM

Code	Functions	Characteristics	Pack Carton
GW 74 363	Without holding	Not illuminated	10/60
GW 74 364	With holding	Not illuminated	10/60
GW 74 366	Without holding	Backlit	10/60
GW 74 367	With holding	Backlit	10/60

SUPPLIED: 3-seat flange (2 of which are contact-holders).
NOTE: compatible with the emergency enclosure GW42204.
CHARACTERISTICS: GW74366 and GW74367 can be combined with the lamp-holder GW74511 + LED lamp.
Also compatible with the watertight emergency enclosure GW42204 and GW42207.

EMERGENCY PUSH-BUTTONS

GW 74 361

ROUND MUSHROOM-HEAD EMERGENCY BUTTONS - MUSHROOM Ø 40MM

Code	Functions	Characteristics	Pack Carton
GW 74 361	With holding	Not illuminated	10/60
GW 74 362	With holding and key	Not illuminated	10/60
GW 74 365	With holding	Backlit	10/60

APPLICATION: suitable for emergency use, in accordance with Standard IEC 60947-5-5.
SUPPLIED: 3-seat flange (2 of which are contact-holders).
NOTE: all the keys are supplied with a standardised code.
CHARACTERISTICS: GW74365 can be combined with the lamp-holder GW74511 + LED lamp.

SELECTORS

GW 74 401

ROUND LEVER SELECTORS WITH FIXED POSITION

Code	No. gangs	Type	Pack Carton
GW 74 401	2	0 - 1	10/60
GW 74 402	3	1 - 0 - 2	10/60

CHARACTERISTICS: operator in thermoplastic material.
Also compatible with the watertight emergency enclosure GW42204 and GW42207.
SUPPLIED: 3-seat flange (2 of which are contact-holders).

GW 74 411

ROUND KEY SELECTORS WITH FIXED POSITION AND REMOVABLE KEY

| Code	No. gangs	Type	Pack Carton
GW 74 411	2	0 - 1	10/60
GW 74 412	3	1 - 0 - 2	10/60

CHARACTERISTIC: operator in thermoplastic material.
SUPPLIED: 3-seat flange (2 of which are contact-holders).
**NOTE:** all the keys are supplied with a standardised code.

Dimension tables

## INDICATORS

23.1

Ø 28.8

PUSH
TOP

45.8

Ø 23.4

26.9   11

30

GW 74 301 ÷ GW 74 306

23.1

Ø 28.8

PUSH
TOP

45.8

Ø 23.6

26.9   19

11

30

GW 74 311 ÷ GW 74 316

23.1

Ø 28.8

PUSH
TOP

45.8

Ø 23.6

26.9   19

30

GW 74 341 ÷ GW 74 345

23.1

Ø 40

45.8

26.9   20.6

11

30

GW 74 363 - GW 74 364
GW 74 366 - GW 74 367

CONTROL AND SIGNALLING

74 PS

Dimension tables

GW 74 361 - GW 74 365

GW 74 401 - GW 74 402
GW 74 421 - GW 74 422

GW 74 451 ÷ GW 74 455

GW 74 501 - GW 74 502

GW 74 503 ÷ GW 74 505